B&U FAN COMPANY

DC Fan 43 in. Quick Connect Extension Wire for use with extension downrods greater than 18 in. in length

How to use the Quick Connect Extension wire:

1. Slide the yoke cover with opening facing down towards the fan onto the downrod. Next slide the canopy cover on to the downrod with opening facing up (as shown in illustration below). If your fan comes with a canopy ring, insert this in between the yoke cover and canopy.
2. Prior to installing the downrod on to the ceiling fan, connect:
    - The blue/white extension wire to the same color wires coming from the top of the ceiling fan. Ensure the colors on the wires match each other (blue to blue, white to white)
    - The Grey/Yellow/Red extension wire to the same color wires coming from the top of the ceiling fan. Ensure the colors on the wires match each other (red to red, yellow to yellow, grey to grey)
3. Feed both wire sets through the extension down rod starting at the end nearest to the yoke cover. (Hint: tie a piece of twine to the two ends, feed the twine through the down rod, and then pull the wires through)
4. If you have not done so already, attach the ball from the downrod included with your fan on to the end of the extension downrod.
5. Secure the downrod to the top of the fan per the manual by inserting the cotter pin and clip and tightening the screws



6. Connect the wires to the remote receiver following the instructions in your ceiling fan manual. (Note: the receiver may have a black wire in place of the blue wire- match the white to white and the black to blue)

If you have any questions or need further assistance, please contact us at the number below.

Customer Service

T (770) 486-2000 CUSTOMERSERVICE@BLUEMOUNTAINFANS.COM